



701 Decatur Avenue North, Suite 107 • Minneapolis, MN 55427 • +1-763-746-8034 • www.rjs1.com

Explanation of the changes between RJS Inspector 5000 Firmware version 0.986

The Inspector 5000 firmware 0.986 changes from the previous 0.985:

- Changed detection threshold used to detect CR2/CR3 Laser scanners
- Added support for using the Laser trigger to exit low-power mode - if trigger is held scan mode starts after a small startup delay
- Changed NBW calculator from a popup to a primary screen to be consistent with other sub-screens